

Barcode TD

Product Introduction

This is the simple user's manual, for detailed manual, please download from our website or contact the supplier.
(With * is the Default Setting)



Factory Default

If scanner cannot be used normally due to an error setting, try to scan the "Factory Default" code above.

Buzzer Description

Two medium high voice	Successful pairing
One medium long high voice	Successful scanning
Three continuous short voice	Alarm prompt

Wireless Transmission Mode



*2.4G



Bluetooth

Version Information



Scanner Version Information



Receiver Version Information

Data Transfer Mode



* Immediate mode



Inventory mode



Clear all data



Number of stored data



Upload all data

Receiver Pairing



2.4G Receiver Pairing

Scanning the "Receiver Pairing" code, scanner will enter the automatic pairing mode for 1 minute, then re-insert the receiver to the host. There will be a sound heard when pairing successfully.



Bluetooth HID Pairing

Scan the "Bluetooth HID Pairing" barcode, the scanner is ready to be connected by other bluetooth devices.

Interface Type



* USB-HID



USB Virtual Com Port

(Driver is needed for USB Virtual Com Port)

Language



*USA



France



Germany



Turkey Q

Sleep Time



Sleep Immediately



1 min



* 5 min



30 min

Language



Brazil



Italy



Spain



Universal language

*For more languages setting, please refer to the full manual.

Terminator



NONE



*CR



LF



TAB



CR/LF

Revision #2

Created 4 October 2024 07:20:16 by Nguyễn Quốc Hưng

Updated 4 October 2024 07:30:35 by Nguyễn Quốc Hưng